






Crossarm Cover



CROSSARM COVERS—COB11173-1

These covers are mainly intended to avoid the contact between the wire formed loops and the crossarm when changing the pin or post insulator.

Can also be used for support of temporary jumpers or conductors over the crossarm. When supporting conductors, the conductor must be protected with a suitable cover.

Available in three models, one for use on crossarms with pin insulators and the others for use on crossarms with post insulators.

CROSSARM COVER-UP

Cat. No.	Description	Length		Approx. Weight	
		mm	ft	kg	lb
RM4933	With pin insulators	610	2.0	1.45	3.20
COB11173-1	With post insulator	570	1.9	1.50	3.31
COB11173-2	Short-type with post insulator	430	1.4	1.10	2.43



WEB: www.austutilities.com.au
EMAIL: sales@austutilities.com.au

PHONE: 08 9406 3200